

Address (Register)	Parameter Number	SDM630Modbus Parameter		Modbus Protocol Start Address Hex	
		Beschreibung	Einheit	Hi Byte	Lo Byte
30001	1	Phase 1 line to neutral volts.	Volts	00	00
30003	2	Phase 2 line to neutral volts.	Volts	00	02
30005	3	Phase 3 line to neutral volts.	Volts	00	04
30007	4	Phase 1 current.	Amps	00	06
30009	5	Phase 2 current.	Amps	00	08
30011	6	Phase 3 current.	Amps	00	0A
30013	7	Phase 1 power.	Watts	00	0C
30015	8	Phase 2 power.	Watts	00	0E
30017	9	Phase 3 power.	Watts	00	10
30019	10	Phase 1 volt amps.	VA	00	12
30021	11	Phase 2 volt amps.	VA	00	14
30023	12	Phase 3 volt amps.	VA	00	16
30025	13	Phase 1 volt amps reactive.	VA _r	00	18
30027	14	Phase 2 volt amps reactive.	VA _r	00	1A
30029	15	Phase 3 volt amps reactive.	VA _r	00	1C
30031	16	Phase 1 power factor (1).	None	00	1E
30033	17	Phase 2 power factor (1).	None	00	20
30035	18	Phase 3 power factor (1).	None	00	22